


SCE Compressor

SECOP



- 01 - Compressor cover
- 02 - Suction connector
- 03 - Discharge connector
- 04 - Service connector
- 05 - Internal discharge tube
- 06 - Discharge muffer screw
- 07 - Discharge muffer gasket
- 08 - Crankshaft
- 09 - Piston pin
- 10 - Conrod
- 11 - Piston
- 12 - Upper bearing
- 13 - Crankcase
- 14 - Valve plate gasket
- 15 - Suction valve

- 16 - Valve plate
- 17 - Discharge valve
- 18 - Discharge valve stopper
- 19 - Valve package rivet
- 20 - Cylinder head gasket
- 21 - Suction muffer
- 22 - Cylinder head
- 23 - Cylinder head screw
- 24 - Rotor
- 25 - Stator
- 26 - Transport stopper
- 27 - Stator screw
- 28 - Oil pump
- 29 - Suspension spring
- 30 - Compressor housing
- 31 - Hermetic terminal
- 32 - Hermetic terminal shield
- 33 - Base plate

