
SECCP



Medical Cooling Solutions











SECCP



Medical Cooling Solutions





R170 - R290 - 100 - 240 V | 50/60 Hz

MN UV, MS UV ULT Compressors

ULT Medical Cooling Stationary Variable-Speed Compressors

- → Reduction of variants thanks to a wide cooling capacity range
- → Ideal solution for new highly effective mRNA-based vaccines for COVID-19, Ebola, and CGTs which require an ultra-low temperature storage
- → One global reach electronic variant (90-270 V, 50-60 Hz)
- → GFCI compatibility for USA (low touch current level)
- → Variable cooling range for precise cooling and temperature control
- → Electronically controlled variable-speed drive compressors
- → Easy °CCD (Cool Capacity Drive) controller customization via Tool4Cool®
- → Robust compressors for medical use and ULT refrigerant approved
- → Optimized for green refrigerants R290 (propane) and R170 (ethane)





















MN UV, MS UV ULT Compressors

New Battery-Driven Solution – Smaller and More Efficient



Series	Applications Evap. Temp Range	Displacement (cm³)	Cooling Capacity (W)	Test Conditions	Refrigerants
		└────────────────────────────────────	0-1000		
MN U/UV	Ultra-Low Temperature Freezers -60 to -90 °C	11.15 – 12.55	182 – 397	pe= -90° pc= -35° Tsuc= 20° Tliq= -35° Tamb= 32.2°	R170 R290 HC mixture
MS U/UV		17.69 – 20.95	234 – 477		



Learn more about the MN UV, MS UV Compressors



SECCP



Medical Cooling Solutions



R170 - R290 - 12-24 V DC

ULT Mobile Cooling


Active Mobile Medical Cooling Technology


- → Safe active fully automated mobile solution based on a 2-stage speed controlled compressor cascade system with a flexible temperature range from -20 °C to -86 °C even in tropical ambient conditions (43 °C)
- → Ideal solution for mains voltage independent transport and storage of mRNA-based COVID-19 and Ebola vaccines and CGT specimens
- → Low energy consumption and fast pull-down time using low GWP green hydrocarbon refrigerants
- → Reliable and precise temperature setting and control and reduced risk of wasting temperature sensitive specimens and vaccines
- → Reliable long-lasting system with low TCO life cycle
- → Designed for AC/DC global voltage range and optimized for low grid areas
- → Easy °CCD controller customization via Tool4Cool® software


















ULT Mobile Cooling

Active Mobile Medical Cooling Technology



Series	Applications Evap. Temp Range	Displacement (cm³)	Cooling Capacity (W)	Test Conditions	Refrigerants
		0-35	0 – 1000		
Mobile ULT Condensing Units	Ultra-Low Temperature Freezers -60 to -90 °C	2	26.7 – 47	pe= -90° pc= -35° Tsuc= 20° Tliq= -35° Tamb= 32.2°	R170 R290



Learn more about the **ULT Mobile Cooling**



R170 - R290 - 100-240 V | 50/60 Hz

ULT Stationary Condensing Unit

ULT Medical Cooling Stationary Casacade Condensing Unit

- → Arrangement of components on the baseplate is optimized for perfectly cooling compressors and controllers to allow high operational load at high ambient temperatures
- → High effective oil separator in low-temperature stage to ensure operation without capillary tube problems and perfect heat transfer (= best possible energy efficiency) inside the evaporator
- → Internal heat exchangers to keep refrigerant temperatures at non-critical levels in all operating conditions and to offer the best possible overall energy efficiency
- → Compact design of the condensing unit and perfect accessibility of tube and electrical connectors for installation in the cabinet
- → Highly efficient variable-speed compressors with very a broad power range for managing pull down and high load operation at high ambient temperatures as well as very energy efficient operation at stable temperatures
- → Premium multi-voltage controllers, optimized to maximize the compressor efficiency and designed to include various in/out configurations as well as additional control features



















ULT Stationary Condensing Unit

ULT Medical Cooling Stationary Casacade Condensing Unit



Series	Applications Evap. Temp Range	Displacement (cm³)	Cooling Capacity (W)	Test Conditions	Refrigerants
		└────────────────────────────────────	└────────────────────────────────────		
Stationary ULT Condensing Units	Ultra-Low Temperature Freezers -60 to -90 °C	17.69	234 – 477	pe= -90° pc= -35° Tsuc= 20° Tliq= -35° Tamb= 32.2°	R170 R290



Learn more about the **ULT Stationary Condensing Unit**





Tailored for Vaccine Refrigerators

Solar Direct Drive System


Solar Direct Drive and Weak Grid Power Management System


- → AC/DC solution optimized for photovoltaic solar panel supply and weak AC grid installations
- → Increased maximum PV voltage to 55 V to enable the use of popular PV modules
- → Power input management and peak power point tracking to ensure efficient and optimal use of PV energy
- → Enhanced communication interface for operation and monitoring
- → AC wide working range between 85 V and 264 V
- → Additional 24 V DC output suitable for data loggers, monitoring devices, USB chargers, and external auxiliaries
- → Designed for premium robustness and reliability: IP60 housing and robust against EMI
- → Designed in combination with the new MB3CKV version of the BD Nano premium series compressor: premium cooling performance with the best efficiency
- → Tailored to WHO PQS requirements and monitoring systems





















Medical Cooling Solutions


New SDD Power Management Module

View more Features




Solar Direct Drive System

Solar Direct Drive and Weak Grid Power Management System



Series	Applications Evap. Temp Range	Displacement (cm³)	Cooling Capacity (W)	Test Conditions	Refrigerants
		0-35	└────────────────────────────────────		
MB CKV	Solar Powered Vaccine Refrigerators -30 to 5° C	2.6	66–133	ASHRAE MBP	R600a



Learn more about the **Solar Direct Drive System**

New SDD Power Management Module




Communication interface for master controller



Cloud data logger



PV panels



AC wide range



24V DC aux output
















Power output and to compressor controller (ECU)



Temperature input (NTC or thermostat)







Fan output